BROBO GROUP©

AUSTRALIAN MADE AND OWNED

Certified System Quality ISO 9001

PRODUCT AND MAINTENANCE MANUAL

METAL CUTTING SAW

MODEL No. S315G, S350G, S400G



• Precision Drilling Machines • Tapping Machines • Multi-Head Drills • Tool Grinders
• Tool Post Grinders • Machine Vices • Special Production Equipment • Accessories
• Riveting Machines • Pedestal Grinders • Metal Cutting Saws • Linishers

OPERATING MANUAL FOR BROBO GROUP
MANUAL METAL CUTTING SAWS

CHAPTER 1: TECHNICAL SPECIFICATION
Standard Blade Sizes
Blade Selection Chart
Motor Specifications
Cutting Range
Dimensions & Weight

CHAPTER 2: **INSTALLATION**
Unpacking & Handling the Machine
Parts Checklist
Minimum Requirements
Anchoring the Saw
Connection to Power Source

CHAPTER 3: SAFETY & PREVENTION
General Requirements
Noise Level
Power Supply
General Requirements
Advice for the Operator
Machine Safety Devices
Reference Standards

CHAPTER 4: MAIN FUNCTIONS & OPERATIONS
Cutting Head
Saw Safety Guard
Saw Handle (with 'Dead Man' Trigger Switch)
Main power standby & Speed selector switch
Manual Vice Clamp
Preparation for Operation
Operation Recommendations
Operational Safety Checks

CHAPTER 5: Adjustments for the Saw Unit
Changing the Blade
Adjusting the Cutting Angle
Cutting & Feeding Speeds
Refilling the Lubricator
Adjusting the Brobolube Unit
Lubricating Oil Precautions – Health Hazard Information

CHAPTER 6: Maintenance and Selection of Consumables
Role of the Operator
Maintenance Requirements
General Maintenance of Functioning Components

CHAPTER 7: Troubleshoot
Troubleshooting For Blade & Cutting Problems
General Troubleshooting

CHAPTER 8: Drawings & Spare Parts

CHAPTER 1 – Technical Specification

1.1. STANDARD BLADE SIZES

Outer Diameter (∅ mm)	Thickness (mm)	Bore Size (mm)	Number of Teeth
315	2.5	40	160
350	2.5	40	180
400	3.0	40	220

TABLE 1. *Standard Blade Sizes*

(*) ***Recommendation***

1.2. BLADE SELECTION CHART

	Material Outer Diameter (∅ mm)	Wall Thickness (mm)	Blade Diameter (∅ mm) & Number of Teeth		
			315	**350**	**400**
HOLLOW CROSS-SECTION	20	1	320	350	400
		2	240	280	340
		3	180	220	240
	40	1	320	250	400
		2	220	260	280
		3	160	180	200
		4	140	160	180
	50	1	320	350	400
		2	220	280	300
		3	180	200	220
		4	160	180	200
		5	140	160	180
	80	1	300	320	360
		2	200	220	240
		3	200	200	220
		4	160	180	180
		5	140	160	180
	100	1	300	300	340
		2	220	200	220
		3	200	180	180
		4	160	140	160
		5	140	120	140
	120	1		300	340
		2		200	220
		3		180	180
		4		160	160
		5		120	140
SOLID SECTIONS	10		280	280	300
	20		160	200	240
	30		140	160	200
	40		120	140	140
	50		80	100	120
	60			80	100

TABLE 2. *Blade Selection Chart*

NOTE - CHART GUIDE ONLY



*This chart is issued as a **guide only**. Many other factors would attribute to the cutting performance of both the saw blade and the cutting saw machine. BROBO GROUP Pty. Ltd. will not accept any responsibility for the blade selection and/or machine breakages or unsatisfactory cutting performance of both the blade and/or the machine as a direct result of the selection.*

Blade Type: AISI M-Z High-Speed Steel (62-64 HRC, Hollow Ground)

Blue-oxide coated for:

- Greater durability,
- Better coolant conveyance to the cutting edge,
- Reduces galling or "pick-up" on sides of the blade,
- Reduces brittleness of the steel.

Tooth Form: Bevelled on alternate sides - up to 180 teeth, or
High-rolling, low-finishing teeth, "triple-chip" - above 180 teeth

Drive Pin Holes (Qty. × ∅ × PCD):
S315 & S350 Series 2 × 8mm × 55mm
S400 Series 2 × 10.5mm × 64mm

Worm Gear Drive Ratio (S315/S350/S400): 1:33 Reduction No of Starts (Shaft) : No. Teeth (Wormwheel)
Sound Level (dBA): 85 - 90 dB (A) Maximum

1.3. MOTOR SPECIFICATIONS

Motor Type (Hz)	Phase	Voltage (V)	RPM	Kilowatt (kW)
50Hz Power Supply	1	240	1430	1.7
50Hz Power Supply	3	415	1420 / 2680	1.5 / 2.2
50Hz Power Supply	3	415	650 / 1350	1.1 / 1.5
60Hz Power Supply	1	230	1700	1.7
60Hz Power Supply	3	220	850 / 1700	1.1 / 1.5
60Hz Power Supply	3	440	850 / 1700	1.5 / 2.2
60Hz Power Supply	3	220	1700 / 3400	1.1 / 1.5

Table 3. *Motor Specifications*

BLADE SPINDLE RPM

Motor Type			BLADE SPEEDS					
			S315		S350		S400	
Frequency (Hz)	Phase	RPM	RPM	m/min	RPM	m/min	RPM	m/min
50	3	650	21	20	21	23	21	27
	1 / 3	1350/1420	42	40	42	47	42	53
	3	2680	85	80	85	93	85	106
			RPM	ft. /min	RPM	ft. /min	RPM	ft. /min
60 (USA)	3	850	26	84	26	93	26	106
	1 / 3	1700	52	168	52	186	52	212
	3	3400	103	334	103	370	103	424

TABLE 4. *Blade Spindle RPM*

VICE CLAMPS

	Manual Vice
Clamping Range (mm)	0 - 153 (158 without wear plates)
Air Requirements:	
Air Consumption (L):	
Clamp Working Pressure (kPa):	
Maximum Pressure (kPa):	
Pneumatic Stroke (mm):	
Clamping Force (N):	

TABLE 5. *Vice Clamps*

1.4. CUTTING RANGE

CUTTING RANGE / PRODUCT		315G	350G	400G
Specifications are for **NEW** blades only. Cutting dimensions will reduce with re-sharpening of blades	90°	100	118	140
	45°	100	110	125
	90°	90	105	115
	45°	80	90	105
	90°	80 x 120	85 x 150	100 x 150
	45°	80 x 80	95 x 110	100 x 110

TABLE 6. *Cutting range*

Note: The above values are based on a full-size blade. The capacities will reduce accordingly when a worn blade is resharpened.

1.5. DIMENSIONAL & WEIGHT

Base Dimensions (L × W): 550mm × 660mm

Table Working Height: 968 mm

Saw Height: 1917 mm

SAW WEIGHT

	Un-Packed Weight (kg)		Packed Weight (kg)	
S315/S350/S400 Saw Unit	136kg	(300lb.)	150kg	(330lb.)
Coolant Tank Complete	17kg	(42lb.)	17kg	(42lb.)
Sheet Metal Stand S315/S350/S400	28kg	(62lb.)	28kg	(62lb.)
Manual Vice Unit	25kg	(55lb.)	25kg	(55lb.)

TABLE 7. *Saw Weigh*

CHAPTER 2 - Installation of the Machine

2.1. Unpacking & Handling the Machine

WARNING – HEAD HEAVY MACHINES

The metal sawing machines are heaviest where the saw heads are fitted & as such, care must be taken while relocating or moving the machines.

Upon receiving the ***Brobo Group S315/S350/S400 Series Metal Cutting Saw***, the machine should be standing upright & positioned centrally on top of a wooden pallet. While the machine is situated on the pallet, position the forklift arms under the pallet between the runners, keeping in mind that the machine is **head heavy**. Move the entire unit to an accessible area as close as possible to the final location.

Carefully remove the wooden frame surrounding the saw unit (Figure 1). Once completed, proceed by elevating the machine away from the pallet base using a sling harness wrapped around the cutting head of the saw. Ensure that the floor is as level as possible before finally positioning the machine to the desired location.



FIGURE 1. *Handling of Metal Cutting Saw Unit*

2.2. Parts Checklist

Along with the saw unit, check that the following accessories, packed "loose", are included as follows:

A. STANDARD ACCESSORIES

1) 1 × Saw Blade
2) 1 × Operating Handle
3) 1 × Service Kit (Allan Key 10mm & 14mm)
4) 1 × Operating Manual

B. OPTIONAL ACCESSORIES

Part Number	Description
9311270	Standard Adjustable Length Stop (600mm)
9501450 9501470	'*Brobo-Rule*' Series Manual Micro-Adjustment Length Stop ▪ Available in 3.0m or 6.0m lengths ▪ Field Kit includes rail, tape, micro-stop & extension arm.
9501210	Roller Conveyor ▪ 68 Kg Steel Rollers ▪ 3000mm x 305mm ▪ 150mm pitch
9311060 9301950	Manual Mechanical Vice Clamp Manual Mechanical Dual Arm Vice Clamp
9501740	Fabricated Sheet Metal Stand
9301450	Floor Stand, Angle Iron
9301400	Trigger 'Deadman" Switch
9501640	S350G & S400G Brobo Synthet 971 Soluble Coolant
-	Additional Blade(s) - *Custom to Client Requirements*

2.3. Minimum Requirements

For the machine to function correctly, the room in which the saw unit is to be installed must be in the vicinity of, & satisfy the following conditions:

- *415/240V Power Supply*
- *Ambient Temperature - From -10℃ to +50℃.*
- *Relative Humidity: Not more than 90%.*
- *Lighting: More than 500 LUX.*



WARNING – OPERATING VOLTAGE VARIATION

Each saw model has an inbuilt safety system to protect it against voltage variations. However, for the machine to perform efficiently, ensure that the saw unit operates within ±10% limits of the recommended voltage of the motor.

2.4. Anchoring the Saw

Prior to anchoring the saw unit, take into considerations the requirements mentioned in *Section 1.3* & *Section 2.2*, & other aspects regarding the usage of the machine such as accessibility to cut parts & safe access for the operator. The base of the fabricated stand (if applicable), in which the saw head rests on, is anchored to the floor by 4 × M12 bolts provided. For added stability, it is strongly recommended that the machine stand is fastened to the floor by using loxins (not provided). When positioning & fastening the unit, please refer to the hole locations shown in *Figure 2*.

BENCH MODELS *(Fig. 2.1 & 2.2)*




Figure 2.1




Figure 2.2

FLOOR MODELS *(Fig. 2.3 & 2.4)*




Figure 2.3




Figure 2.4



Figure 2. *Anchoring Hole Locations*

2.5. Connection to Power Source

Before connecting the machine to the power supply, check that the socket is not connected in series with other

Single & Three Phase

a) **Single phase machines** are provided with three pins, **15 amps** rated plugs & leads for connection to **240V**, **50Hz** power supply in **Australia**.

Active = Brown **Neutral = Light Blue** Earth = Green/Yellow	**VOLTAGE** **240V/1 PH**	**MAIN VOLTAGE** **240V**



Figure 3.1

b) **Three phase machines** should be fitted with a suitable, approved **four pin plugs** (i.e. three phase & earthing - **not provided**)

Active = Brown, White. Dark Blue **Earth = Green/Yellow**	**VOLTAGE** **415V/3PH**	**MAIN VOLTAGE** **415V/3PH**



Figure 3.2

c) Check the power supplied & motor specifications before plugging in the machine. Check the terminal connection on dual voltage motor terminal box & connect it accordingly to the corresponding voltage supply.

d) If the dual motor is requested, the motor is **always** connected to the higher voltage, unless otherwise specified prior to the order being placed.

To connect the machine to the power supply, proceed as follows:

1) Insert the power plug into the socket, while ensuring that the **mains voltage is compatible** for which the saw unit is operating at.

2) Switch the saw on by rotating the control switch located on the saw head assembly as shown in *Figure 4* below.



Figure 4. *Main Control Switch*

3) Check that the motor is operating in the correct direction, that is the blade is rotating downwards & into the direction of the vice clamps.
4) Ensure that all electrical leads & cables (including supply leads) are maintained in a good condition & away from sharp objects. All leads should be replaced if cut, sliced or damaged in any way.

***Brobo Group S315/S350/S400 Series Metal Cutting Saw** is now ready for use.*

CHAPTER 3 - Safety & Accident Prevention

The ***Brobo Group*** ***S315/S350/S400 Series Metal Cutting Saw*** has been designed & manufactured in accordance with **Australian Standards**. It is ***HIGHLY RECOMMENDED*** that the instructions & warnings contained in this chapter be carefully followed for correct usage of the machine.

3.1. Operation of the Machine

The ***BW S315/S350/S400 Series Metal Cutting Saw*** is specifically designed to cut ferrous & non-ferrous metal cross sections with solid or thin-walled profiles. Other types of material & machining are not compatible for use with the specifications of the saw. ***This machine involves a high-speed blade rotation; therefore extreme caution is required when operating the device.***

The employer is responsible for instructing the personnel who, in turn, are obliged to inform the operator of any accident risks, safety devices, noise emission & accident prevention regulations provided for by national & international laws governing the use of the machine. ***The operator must be fully aware of the position & functions of all the machine's controls.***

All those concerned must strictly adhere to ALL instructions, warnings, & accident prevention standards in this manual.

The following definitions are those provided for by the ***EEC DIRECTIVE ON MACHINERY No. 98/37/CE***:

- **Danger Zone -** any zone in and/or around a machine in which the presence of a person constitutes a risk for the safety & health of that person.
- **Person Exposed** - any person finding him or herself, either completely or partly in a danger zone.
- **Operator** - the person or persons are given the responsibility of installing, operating, adjusting, maintaining, cleaning, repairing, & transporting the machine.



WARNING – UNAUTHORISED MODIFICATIONS/REPLACEMENTS/USE

The manufacturer declines any responsibility whatsoever, either civil of criminal, in the case of unauthorised interference or replacement of one or more parts or assemblies on the machine, or if accessories, tools & consumable materials used are different from those recommended by the manufacturer, or if the machine is inserted in a plant system & its proper function is altered.

3.1.1. Noise Level

The noise level of an idling metal saw, fitted with a ***180-tooth blade*** (supplied as standard by ***Brobo Group***) has been measured to be ***below 85 dBA***. This complies with the ***Australian Occupational Health & Safety (Noise) Regulations 1992.***

Please note that peak impulse noise levels will be experienced due to variables including blade characteristics, type, & condition. This will also vary accordingly depending on the size & type of sample being cut. Under these circumstances, management should make available to the operator(s) the appropriate hearing protection equipment as prescribed under the above-stated act.

3.1.2. Power Supply

The 415/240V power supply requirements for this machine are of a high level & unauthorized interference and/or inadequate maintenance could result in a situation that could put the operator at risk. A ***qualified*** electrical engineer should always be assigned to maintain & repair the system.
International Protection Rating code (Ingress Protection): **IP54**

First Digit: Solid - Level 5: *Protected from limited dust ingress.*
Second Digit: Liquid – Level 4: *Protected from water spray from any direction.*

3.1.3. Compressed Air Supply

Various functions of the saw are carried out via the use of 6 bar compressed air. During these operations, situations would arise where machine parts & materials are clamped together & would potentially pose a serious safety issue to an inexperienced operator. Operators should be thoroughly instructed about these hazards.
Only a qualified electrician should carry out regular maintenance of this system.

3.2. General Requirements

Lighting
Insufficient lighting during the operation of the saw unit would constitute a safety hazard for the people concerned. For this reason, the user of the machine must provide adequate lighting in the working area to eliminate areas of shadow, whilst also prevent dazzling illumination sources
(Reference standard ***ISO 8995 - 2002 'Lighting of Indoor Workplaces'***).

Connection
Check that the power supply cables, compressed air supply (if applicable) & coolant system complies with, & are operating within the acceptable range of the saw capabilities.
Faulty, damaged or worn components must be replaced immediately.

Earthing Systems
The installation of the earthing system must comply with the requirements stated in the:
IEC Standards Part 195: Earthing & Protection Against Electric Shocks 1998.

Position of the Operator
The user controlling the machine saw operations must be positioned as shown in *figure 5* below.



Figure 5. *Correct Position for Operating Saw Unit*

3.3. Advice for the Operator



Protective eyewear or goggles must be worn at all times while attending & operating the metal saw.



Do not attempt to operate the machine unless all safety guards are in operation.
The guard must fully cover the blade when the head is in the uppermost position.



Ensure that ***hands & arms are kept clear of the cutting zone*** when the machine is operating.



Do not wear loose clothing with long sleeves & oversized gloves, bracelets, necklaces or any other loose object that may become entangled in the machine's blade during cutting. Long hair must be tied back or placed in a hair net.



Always disconnect the power supply to the machine before carrying out any maintenance work or adjustments. This includes cases of abnormal operations of the machine.



Any maintenance work performed on the hydraulic, pneumatic or coolant systems must be carried out only after the pressure in the system has been released.



The operator ***MUST NOT*** conduct any risky operations or those not required for the cutting in course (e.g. remove swarf shavings from the machine while cutting).
Never move the saw while the machine is operating.



Always keep the workplace are as clean as possible.
Remove equipment, tools or any other objects from the cutting zone.



Support the workpiece on both sides of the machine to prevent it falling or jamming during the cutting cycle.



Ensure that the specimen being cut is secured firmly in the vice clamps & the machine has been correctly set. *Figure A* show some examples of how to correctly clamp different specimen profiles. Before commencing the cut, be sure the vice(s) is securely clamped & the machine set-up is correct.





Figure A. *Correct Clamping of Cutting Specimens*



Do not use cutting blades of different sizes to those recommended to the machine's specifications. Always follow safe practices & inspection procedures when installing blades (Please refer to section *5.1 Changing the Blade*).



When cutting very small specimens, ***ensure that the workpiece is not dragged behind the back fence support***, where it could get lodged behind the blade.



If the blade jams during a cut, activate the emergency stop function immediately. Do not continue forcing the blade through. This could damage the blade, the specimen or be a cause for potential injury to the operator.



Always turn off the machine before carrying out any repair work. Consult the Brobo Group Engineering Department in the country in which the machine was initially purchased.

3.4. Machine Safety Devices

This product & maintenance manual is not purely intended as a guide for the usage, operation, & maintenance of the saw unit in a strict production environment; it is instead an instrument to providing information on how to use the machine correctly & safely. The following standards listed in section *2.4.1*, which are applicable to the ***BW S315/S350/S400 Series Metal Cutting Saw***, are those specified by the EEC Committee that governs the safety of machinery, health & safety at work, personal protection & safeguarding of the work environment. In addition, the saw also complies with the Australian Standards regarding the safeguarding & general requirements for electrical equipment.

3.4.1. Reference Standards




MACHINE SAFETY

- *EEC Directive No. 98/37/CE - Machines Directive*
- *EEC Directive No. 91/368 - 94/68 - Amends sections of EEC Directive No. 98/37/CE relating to machine safety*
- *EEC Directive No. 73/23 - Low Voltage Directive*
- *AS4024.1 - 1996 - Safeguarding of Machinery*

HEALTH & SAFETY AT WORK

- *AS3100 - 2002 - General Requirements for Electrical Equipment*
- *OH. & S. 1995.81/1995 - Compliance References*
- *EEC Directive No. 80/1107; 83/477; 86/188; 88/188; 88/642 - Protection of workers against risks caused by exposure to physical, chemical & biological agents in workplace*
- *EEC Directive No. 73/23 & Special EEC Directives No. 89/654; 89/655 - Improvements in health & safety at work*

CHAPTER 4 - Main Functions & Operation of the Machine



4.1.1. Cutting Head

As the name suggests, the cutting head is the focal area where most of the specimen cutting takes place. Thus, correct saw blade selection such as size, number of teeth & tooth pitch are all critical factors that determine the overall performance & quality of the final cuts. In addition, the use of correct saw blade provides minimum burr to the workpiece while maximising the safety to the operator during each cutting procedure.

4.1.2. Saw Safety Guard

The primary purpose of the saw safety guard is to protect the user from the spinning blade. It also functions as a safety device to protect the operator from any broken tooth, swarf or high-velocity particles that might be dislodged by the cutting process.



Figure 6. *Saw Safety Guard*

4.1.3. Saw Handle (with 'Dead Man' Trigger Switch)

Although comes as a standard, the saw handle can be installed with a Dead Man' type trigger switch enabled instant switching at the operator's control. This particular configuration allows for increased efficiency & safety.

Figure 7. *Saw Handle with "Dead Man" Trigger Switch*



4.1.4. Main Power Standby & Speed Selector Switch

The rotary Main power switch also serves as the speed selector switch. When the speed is selected the saw is set to "STANDBY" mode. The "STANDBY" lamp illuminates to provide a warning to personnel the saw is at the ready. AT any time the "Dead Man" trigger is activated the saw will run.

Figure 8. *Standby Lamp*

4.1.5. Manual Vice Clamp

The manual vice clamp lever allows speedy clamping of material with ergonomically designed clamp lock.
Vice Clamp Capacity is **153mm**




Figure 9. *Manual Vice Clamp*

4.1.6. G Model Design

Quick Action Mitering
Larger Cutting Capacity
Heavy-Duty Cast-Iron Table, Back Fence, Pivot Block & Rotary Table.
The saw blade always cut at the centre of the table either standard cutting or any angular cutting without repositioning the wear plates.




Figure 10. *Standard Cut at 0*

4.2. Preparation for Operation

The following procedure is recommended for the correct cutting using the ***BW S315/S350/S400 Series Metal Cutting Saw.***



WARNING – SAFETY GEAR

Protective clothing, safety glasses and gloves should **always** *be worn while loading parts, operating the machine, or undertaking any maintenance work on the machine.*

PROCEDURE

Using a non-flammable & toxic free solvent, clean the machine to remove any corrosion protective coating prior to use.

1) Ensure that both the air & electric power systems are turned on, where applicable. The electrical power source must be available before any pneumatic functions will operate.

2) To adjust the cutting angle, untighten the quick action handle, as shown in *Figure 11*. Fine-tune the angle required, then re-tighten the quick action handle.



Figure 11. *Quick Action Handle*

3) Place the cutting specimen you wish to cut into the vice clamps. Manually adjust the clamps so that the jaws are clamped firmly to the workpiece. With a pneumatic vice, manually adjust the clamps to a clearance of ***3 - 7mm***. (For correct clamping of material, please refer to *section 2.3 Advice for the Operator*). *NOTE* -The vice clamps advance with an approximate ***10mm pneumatic stroke*** to apply a clamping pressure of 6 bar (87 psi).

4) Position the vice clamps & component as close to the blade as possible without interfering with the travel of the blade or guard. Vice relocation is required whenever the head angle is altered.

5) For pneumatic vices, set the vice clamping pressure from the pressure regulators located on the main control unit door. *If for any reason this pressure is not available on a continuous basis, the regulator on the air service unit must be set slightly below the available line pressure, & the safety low-pressure indicator valve needs to be reset to correspond with the newly available pressure. The need to change the pressure is necessary to allow for lighter materials with hollow cross sections to be cut without deforming the walls thicknesses.*

6) To initiate the cutting process, either turn the switch to **1** or **2** settings or press the **START** buttons.
   - Vice jaws automatically close & apply clamping pressure.
   - Position blade to commence cutting through component & maintaining a constant forward feed cutting rate until the end of the stroke.
   - Return saw cutting head to the initial rest position.
   - Vice clamps release workpiece

7) The machine is ready for the next cutting cycle.

4.3. Operation Recommendations

- Select the correct saw blade with the correct tooth pitch & form to suit the material to be cut to provide minimum burr & maximum blade lifespan.
- Use the smallest diameter blade & coarsest pitch that is practical within the required speed & material limitations.
- Generally, use a tooth pitch to give 2 - 4 teeth engagement with the material during cutting.
- Ensure that sufficient coolant is flowing over the cutting teeth.
- Do not allow the machine's gearbox to run idle in the upright position for more than ***3 minutes*** otherwise, damage can occur to the drive system.
- The rate of feed affects the quality of the final cut & blade life. This varies also by the material & cross-sectional dimensions. When cutting stainless steel or high carbon steel (***Brinell hardness above 200***), the slowest speed machine should be used together with a cobalt type high-speed steel blade.
- When manually feeding the saw head, keep in mind to maintain a steady, continuous pressure, thus ***avoiding work hardening*** on the cutting piece. Avoid 'forcing' the blade through the material as this might damage or break the blade.
- As a rule of thumb ***the softer the component, the faster the rate of speed***. Thus, it is recommended that slower speeds be used for hard & tough materials & higher speeds for soft, ductile materials. Note that for non-ferrous materials such as brass, copper, aluminium etc. require much faster speeds than provided on this machine. If these are the majority of materials cut, a *Brobo NF Series* machine should be considered.

4.4. Operational Safety Checks

- Do not attempt to hold the work piece by hand.
- Always use the vice to clamp the work. Properly support any overhanging portion so the work piece is level with the base of the machine.
- Do not have any part of your body in line with the path of the cutting blade.
- Allow the blade to reach full speed before cutting.
- Ease the cutting blade against the work piece. Do not use excessive force when cutting.
- Keep hands away from cutting area. Do not attempt to remove cut material or swarf while blade is moving.
- After finishing the cut, raise the saw arm up, release the switch and wait for the blade to stop completely before removing your work piece or off-cut piece.
- Immediately clean up any coolant spills.
- Before making any adjustments, bring the saw to a complete standstill and disconnect from the AC power source.

CHAPTER 5 - Adjustments for the Saw Unit

5.1. Changing the Blade

To replace a worn saw blade:



DANGER – ELECTROCUTION

Make certain that the power to the manual saw is turned off before proceeding with changing the saw blade.

1) Disengage the linkage arm that is between the guard linkage system & pivot block (at the pivot block by compressing the spring & moving the bolt through the slot).

2) Slide the saw guard up as far as possible (as if it was opening during a cutting cycle) to gain access to the spindle nose.

3) Loosen the spindle screws (LH thread), using the 14mm hexagonal wrench provided, & remove the counter plate. To loosen the spindle screw, insert the wrench (short end) into the socket head cap screw & firmly knock the wrench with the palm of your hands until the screw is loosened. If this method fails to free the screw, place a piece of timber under the blade of the machine, & loosen (or tighten) the screw while holding the saw head of the machine down (blade against the timber).

4) Remove the worn saw blade away from the spindle hub. Using a soft brush, clean the face of the spindle, counter plate & mounting faces of the blade of any dirt or swarf that was trapped by the previous cutting cycles.

5) Place the old saw blade into the new blade packaging & disposed of it safely. Carefully mount the new blade onto the spindle hub, ensuring that the blade is rotating into & towards the back fence, & replace the counter plate utilising the drive pins as guides as it passes through the pinholes on the blade.

6) Rotate blade back against the drive pins in a ***counter-clockwise*** & finger tighten the spindle screw.

7) Firmly retighten the spindle screws, ensuring that the saw blade spins uniformly & aligned parallel with the safety guard.

8) Lower the outer guards & make certain the pin of the linkage arm is re-engaged with the track on the inner guard & reconnect the guard linkage.

9) The new blade is ready for use. To check that the blade is performing correctly, carry out a sample cut on a piece of off-cut.

10) If optional devices are supplied, mount the stock support & rollers on either side of the clamping table. Normally stock should feed on the ***left to right***, but it can be feed from the ***right to left*** if required.

5.2. Adjusting the Cutting Angle

The back jaw wear plates on the ***Brobo Group S315/S350/S400 Series Metal Cutting Saw*** are typically fitted in the following manner. (*Figure 12*).




Figure 12. Angular Cut Positions

i. To adjust the cutting angle, untighten the quick action handle, as shown in *Figure 10.*

ii. Adjust the angle on the rotary table to suit. (Self-locating pin locates at 90⁰ & 45⁰ left & right)

iii. Re-tighten the quick action handle. The saw is now ready for use.

5.3. Cutting & Feeding Speeds

As previously highlights, the rate of feed largely affects the quality of the final cut. As such, the blade life is also dependent on the feed at which it is cutting the sample material - in particular, the type of material & also the cross-sectional dimensions. Thus, to extend the life of the blade, maintain a firm & steady pressure whilst allowing the blade teeth to cut at an optimum rate. ***Do not force the blade through the material!*** This could cause numerous problems including breaking the blade teeth, jamming the blade with the cutting part or fracturing the blade spindle.

The cutting action also generates a large amount of heat within the cutting sample due to frictional contact. Should this heat affect the material you are cutting in any way, the heat should be dissipated using the coolant system.

5.4. Refilling the Lubricator

To refill the lubricator bowl, twist the bowl anti-clockwise & slide it down to detach it from the lubricator unit (There is no need to disconnect the air supply to the unit). The unit can now be refilled to the line positioned near the top of the bowl, which is approximately 10 millimeters from the top edge of the bowl. ***Do not fill the bowl above this line****,* as the lubricator unit will not function properly.
Replace the lubricator bowl in a reverse manner by sliding the bowl upwards, ensuring that the feed tube is located inside the bowl, & twist it clockwise to lock it into position.

5.5. Adjusting the Brobolube Unit

When assembled, the Brobolube unit is a precise instrument that supplies an accurate quantity of lubricant directly to the saw blade before it contacts the workpiece. There are 2 control variables available for the operator:

Air Flow (Volume) Delivery

Regulated with the tap (needle valve), this can be adjusted from initial, completely closed to fully open states. It is highly recommended that the upper end of the flow range be utilized to allow an adequate airflow to deposit & evenly distributed the lubricant onto the blade while maintaining a fine lubricant mix. If the needle valve is not open sufficiently, the air to lubricant ratio may vary & may result in a substandard distribution of lubricant to reach the blade teeth.

Lubricator Flow Rate

This controls the fluid flow rate & is adjustable via the slotted needle valve situated on top of the lubricator. The consumption of Brobolube is factory set to ***4 drops per minute***. This has been examined to produce a sufficient mix of air & lubricant, & it is recommended to use this initial setting. On this setting, approximately ***55 cubic centimeters*** (lubricator capacity) should last for ***20 hours of continuous cutting***. If for some reason the setting needs to be altered, the needle valve should be turned clockwise to reduce or anti-clockwise to increase the fluid flow respectively.

NOTE

i. Although the lubricator is capable of delivering a much higher flow rate of lubricant, it is suggested that you do not increase the flow rate excessively because:

- No significant increase in blade life or lubricating efficiency will be achieved (confirmed by test results).
- Excessive application of Brobo Synthet 971 Soluble Coolant will only result in a waste of fluid.
- The excessive application will produce swarf that will be wet (oily) & harder to clean up than dry swarf produced from the correct supply of Brobo Synthet 971 Soluble Coolant.

ii. The amount of Lubricant (when set correctly) delivered by the lubricator is not easily visible to the naked eye. If in doubt that lubricant is being delivered, first check to see if lubricator itself is delivering droplets at its sight glass. If still unsure whether lubricant is being delivered, disconnect the supply tubing to the tap (needle valve) & hold the tube against some blotting paper for a few seconds while the lubricator is operating.

5.5.1. Lubricating Oil Precautions - Health Hazard Information

The Brobo Synthet 971 Soluble Coolant lubricating fluid has no known adverse health effects. "Brobo Synthet 971 Soluble Coolant" is non-toxic, odourless, non-flammable below approximately 350ºC, & non-corrosive, although it may affect some types of rubber. There are no traces of sulfur, chlorine, phenol or nitrates found in Brobo Synthet 971 Soluble Coolant. When comes into contact with skin, the oil may be removed by wiping away the excess, then washing the contaminated area with detergent & water. If the oil is utilized at high temperatures, appropriate protective apparel should be worn as the oil could cause burns to skin or eyes. If splashed by hot oil, immediately run cold water over the burn area & apply first aid burn treatment.

If the Brobo Synthet 971 Soluble Coolant delivery line breaks or becomes disconnected during operation, ensure that the air supply to the system is disconnected before repairing the problem.

It is recommended that footwear with anti-slip soles be worn at all times. Any spills will result in potentially hazardous slippery surfaces & should be dealt with promptly to prevent physical injury resulting from falls. Do not use coarsely, combustible material like sawdust to soak up oil due to the potential risk of spontaneous combustion. Spilled oil should be transferred into non-porous containers of suitable strength. Any remaining oil should be cleaned up with sand or other non-combustible, absorbent material. Place the sand & oil mixture into containers & disposed of by an EPA approved landfill or alternatively, by a suitable non-polluting method.

In addition, rags soaked in oil should not be burned. Do not pour oil down the drain, which would ultimately contaminate the water supply & pollute the environment.



For firefighting purposes, either use CO2, dry chemical or foam retardant to extinguish the flames.

CHAPTER 6 – Maintenance & Selection of Consumables

6.1. Role of the Operator

The person operating & maintaining the ***Brobo Group S315/S350/S400 Series Metal Cutting Saw*** must familiarise themselves with these instructions for their own safety & that of the others, in addition to safeguarding the production of the machine. Responsibility must be taken by the user on the general maintenance & up keeping of the unit as specified in this chapter, with particular emphasis on:

- Check to ensure that other operators of the machine always aware of & comply with the relevant safety instructions & standards as specified in *Chapter 2 - Safety and Accident Prevention*. Therefore, check that the safety devices are operational & work perfectly & personal safety requirements are complied with.

- Ensure that the working cycle is efficient & guarantees maximum productivity, inspect the:
    - Functions of the main components of the machine
    - Sharpness of the blade & coolant flow
    - Correct working parameters for the type of material being cut

- Verify that the quality of the cut meets the requirements & that the final product is free from any machining defects.

6.2. Maintenance Requirements

- All maintenance must be carried out with the power switched off & the machine in emergency stop condition.

- To guarantee for optimum operation, all spare parts must be Brobo Group originals.

- On completion of maintenance works, ensure that the replaced parts or any tools used have been removed from the machines before starting it up.

- Any behavior not in accordance with the instructions for using the machine specified in this manual may create hazards and/or safety risks for the operator.

- Therefore, read & follow all the instructions for use & maintenance of the machine & those on the product itself.

6.3. General Maintenance of Functioning Components

The general maintenance operations that should be carried out regularly are as follows:

1) Keep the vice clamps, overall machine & path of the cutting blade free of any offcuts, accumulated swarf & coolant using compressed air or preferably thread-free cloth.

2) Observe the oil level on the gearbox. The first oil change should be performed after the initial **60 hours** of operation, and then subsequently at **500 hours of operation or 1 year**, whichever comes first.
   Use Brobo Gearbox Oil (Part No. **9501090)**
   Refilling point is situated in the handle bar mounting threaded hole.
   The required quantity to refill is 800 ml for the S315/S350/400 gearboxes.

3) Change coolant as required, or whenever the coolant starts to get dirty or emits a stale odour. The coolant compensation tank should be checked regularly. Coolant level would expect to naturally decrease over time due to natural evaporation. Use premium quality coolants which are available from BROBO GROUP Pty. Ltd. in 2 liter & 20-liter packs (Part No. **9301570** & **9501080**): Concentrate, Ratio 1:20

4) Lubricate the saw head pivot shaft & rotary table regularly (after every 40 hours of operation, or weekly) with an NLGI 2 extreme pressure grease, Shell Alvania No.1 grease or equivalent.

5) Clean the vice & lubricate any moving joints or sliding surfaces with good quality oil.

6) Clean the machine regularly & keep any unpainted surfaces lightly oiled to protect from rust & corrosion.

7) The air supply for the pneumatic air vices should be checked regularly such that it is free of any condensed water molecules & the filter should be drained frequently.

8) Ensure that the machine performs cuts perpendicular to the work surface.
If not, contact Brobo Group engineering department.

9) Test that the blade is at right angles to the workpiece back fence.
If not, contact Brobo Group engineering department.


10) Check that the 0° notch on the fixed worktable is aligned with the graduation on the turntable. If not, adjust as described in Section 5.2.

11) Examined that the precision of the 15°, 30°, 45° left & right stops are correct & accurate. If they are not adjusted properly, proceed as described in Section 5.2.

12) Regularly empty out the swarf catcher, resting directly above the compensation tank, of any offcuts & swarf that has collected during the numerous cutting cycles.

CHAPTER 7 - Troubleshoot

7.1. Troubleshooting For Blade & Cutting Problems

PROBLEM IDENTIFIED	DIAGNOSIS	SOLUTIONS
Cuts produced are not at 90° and/or are not perpendicular 	Head speed too low or too high	Reduce or increase head speed respectively.
	Blade with worn teeth	Replace with a new blade, with reference to *Section 5.1 Changing the Blade.*
	The angularity of blade to workpiece back fence & vice clamps	Adjust the position of the blade so that it is at right angles to the workpiece back fence using the 0° notch as a reference; set the stops at 45° left & right using the method described in *Section 5.2 Adjusting the Cutting Angle.*
	Blade not perpendicular to the work surface	Adjust the blade using the appropriate screws such that it is perpendicular to the work surface.
Frequent and/or excessive teeth breaking 	Broken teeth	Check the hardness of the material being cut corresponds within the capabilities of the blade.
	Incorrect lubricant/coolant fluid	Check the water & oil mixture; check that the holes and/or hose are not blocked; direct the nozzles correctly; check that the lubricant/coolant fluid conforms to those specified in *Section 6.3 General Maintenance of Function Components.*
	Material too hard	Check the cutting speed, feed speed, blade type, & parameters are correct for the particular application.
	Blade not worn incorrectly	With a new blade, it is necessary to start cutting at *half feeding speed*. After a normalising period (cutting surface about 300cm^2 for hard materials & 1000cm^2 for softer materials), both cutting & feed speeds can be brought up to normal values.

	Blade with incorrect and/or excessive fine tooth pitch	As excessive pressure is exerted on the incorrect teeth profile, replace the blade with correct tooth pitch dimensions & profile.
	Workpiece not clamped firmly in place	Any movement of the workpiece during the cutting process can cause broken teeth; check the vice clamps, clamping jaws & clamping pressure is satisfactory.
	Excessive vibrations	Specimen vibrates in the vice; check that the vice clamps are position correctly & the clamping pressure are adequate.
Rapid teeth wear 	Head speed too slow or too high	The blade/slide runs over the material without cutting it; increase or decrease head speed respectively.
	Cutting pressure to high	Reduce cutting pressure Check the coolant level & clean piping & nozzles
	Insufficient coolant	The material present may not be homogenous either on the surface, such as oxides or sand present or in sections, such as under-cooled inclusions. The variances in grain development cause the premature wearing of teeth & consequently, break as the result. Homogenise or clean these materials.
	The non-homogenous material being cut	
B 	Head speed to high	Reduce head speed
	Teeth in contact with the material before commencing the cut	Always check the position of the blade before starting an initiating a new cut or job
	Insufficient coolant	Check the coolant level & clean piping & nozzles
	Excessive vibrations	Specimen vibrates in the vice; check that the vice clamps are position correctly & the clamping pressures are adequate

7.2. General Troubleshooting

Below lists of some of the most commonly identified problems associated with the ***BW S315/S350/S400 Series Metal Cutting Saw*** & the recommended troubleshooting procedures to undertake to rectify the situations. If the solutions provided do not resolve the problem, or the problem identified differs from those listed, ***immediately*** contact Brobo Group engineering department.

PROBLEM IDENTIFIED	DIAGNOSIS	SOLUTIONS
Spindle motor will not rotate	Electrical power supply not connected	Ensure that the main power cable is plugged in & switched on. Check the phases, cables, plugs, & sockets for loose connection. Also, check that the motor connections are in place.
	Loose contactors	Verify that the contractors are not loose. If contacts are short-circuited, contact Brobo Group engineering department immediately
	Motor burnt out	Check that it has not burnt out, that it turns freely & there is no moisture in the main electrical unit. The winding can be rewound or replaced
	Blown fuses	Examine that the fuses are intact & fitted correctly, otherwise replace or tighten the fuse holders
Machine open slowly or not at all	Hydraulic oil level & pressure system	Check for any leaks present within the catchment unit. Top up the with coolant as recommended in *Section 6.3 General Maintenance of Functioning Components*
Coolant system not operational	Blocked coolant tubing	Check that it is not kinked, severed or blocked. Flush out any blockages


APPENDIX - RISK/HAZARD ASSESSMENT


Hazard Type	Hazard Identification	Hazard Assessment	Hazard Management Strategies (Recommended for the Purchasing / Buyer / User)
Mechanical	Cutting/Severing	Low/Med	▪ Keep machine correctly guarded & operational at all times. ▪ Keep & clear of rotating blade when cutting.
	Entanglement	Low	▪ Do not wear loose jewelry, clothing or items that might get caught in the saw. ▪ Always keep the work area free of unnecessary objects or tools.
	Puncturing	Low	▪ Wear protective gloves when handling and /or changing the blades. ▪ The power source is to be isolated prior to opening electrical enclosures.
Electrical	Electrocution	Low	▪ Remove the power supply when any maintenance and/or repairs are to be undertaken. ▪ The power source is to be isolated prior to opening electrical enclosures.
Thermal	Burn	Low	▪ Under normal working conditions, the gearbox can become hot thus, do not touch. ▪ Be careful when handling workpiece after cutting, as it might be very hot.
Noise	-	Low	▪ Under no load testing, the noise level measured is below 85 dB (A). ▪ If the noise level becomes too high during a cutting cycle, stop the process & inspect for the problem, if any are present.
Substance	-	Low	▪ Care must be taken as some coolants may be harmful or cause allergic reactions. Please read the labels carefully. ▪ Keep the work area clean & regularly remove excess coolant, oils, & other impurities.
Hazardous Events	Unexpected Start-Up	Low	▪ During a power failure, turn the machine off. ▪ If the problem persists, please contact Brobo Group engineering department.
	Failure of Control System	Low	▪ If the ON/OFF switch fails, isolate the machine at the power source. ▪ Ensure that no fuses are blown & that all electrical circuitry are operating within normal parameters.
Additional Hazards	Operator Error	Low	▪ Ensure blades, clamps & materials are correctly secured.
	Impact	Low	▪ Wear safety glasses at all times during cutting cycle.


MACHINE TYPE: _____


SERIAL NO.: _____

RECEIVING COMPANY: _____ (SAFETY OFFICER)









ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT


DRAWN ANH
DATE 02.02.2022
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:


STANDARD COLD SAW PACKAGING


DO NOT SCALE DRAWING SCALE:1:15
DWG NO.
000101
REVISION 0
SHEET 1 OF 1 A3




SAFE WORKING ZONE








INTEGRATED STAND



ANCHORING HOLE
FLOOR MODEL



BENCH MOUNTED

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 23.07.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:

COLD SAW G MODEL

DO NOT SCALE DRAWING SCALE:1:20
REVISION 0
DWG NO.
001001
SHEET 1 OF 1 A3



4 9601680: SPRING UPGRADE (INCLUDED UPPER BRACKET)
9601670 SPRING ASSEMBLY

3 9501300 LINK ASSEMBLY 200mm



2 9732090 QUICK ACTION HANDLE

1 G MODEL ASSEMBLY

- CLAMPING TABLE
- ROTARY TABLE
- BACKFENCE
- PIVOT BLOCK


5 8706150 Linkage Shoulder Bolt M6x5

9301040 DEADMEAN TRIGGER HANDLE & SWITCH ASSEMBLY
9301800 FIELD KIT SINGLE PHASE
9301810 FIELD KIT THREE PHASE 5

GEARBOX & MOTOR ASSEMBLY 6

9542050: OUTER GUARD S350/S400
9342040: OUTER GUARD S300/S315 7

9711060: VICE ASSEMBLY COMPLETE
9701950: DUAL ARM VICE COMPLETE
9301920: AIR VICE SINGLE FIELD KIT
9301930: DUAL AIR VICE FIELD KIT 8



9701740: SHEETMETAL STAND COMPLETE
9735000: SHEETMETAL BOTTOM
9733000: SHORT TANK
9301450: FLOOR STAND ANGLE IRON 9

9311110: COOLANT TANK ASSEMBLY 10


ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN any FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 20.11.2023
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:
COLD SAW INTEGRATED STAND ASSEMBLY

DO NOT SCALE DRAWING SCALE:1:10
DWG NO. **002001**
REVISION 0
SHEET 1 OF 3 A3



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9712000	Clamping Table	1
2	9732070	Back Fence 1P Machining	1
3	9714280	Wear Plate 5mm	2
4	**8706130**	**Flat Countersink M8x12**	**4**
5	8715140	Dowel Pin 12x30	2
6	**8705250**	**Socket Head Cap Screw M12x40**	**2**
7	**8705290**	**Socket Head Cap Screw M12x75**	**2**
8	9732080	Hollow Dowel 19x12.5x24	2
9	9732090	Quick Action Handle M12x50	1
10	9304220	Locking Pad 15.9 x 9.5 (Brass)	1
11	**8706140**	**Socket Head Cap Screw M8x70**	**1**
12	9704770	Hollow Dowel 12x8x24	1
13	8715810	Socket Set Screw M12x16	1
14	9315000	Spring 9.5 x 1.6 x 110 L	1
15	9324180	Pin Lock 10	1
16	8705300	Socket Head Cap Screw M12x100	2
17	8705270	Socket Head Cap Screw M12x60	2
18	9305110	Grease Nipple M8x1.25	1
19	9712020	Rotary Table Bevel Gear 2.5	1
20	9712040	Pivot Block	1
21	8705140	Socket Head Cap Screw M8x35	1
22	8715210	Hex Thin Lock Nut M8	1
23	8705990	Roll Pin 6x24	2
24	8725500	Socket Head Cap Screw M10x35	4
25	9724270	Spring Lower Bracket	1
26	8705230	Socket Head Cap Screw M12x25	3

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 24.06.2022
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:

G MODEL CLAMPING TABLE ASSEMBLY


DO NOT SCALE DRAWING SCALE:1:4
DWG NO. **9712500**
REVISION 0
SHEET 2 OF 3 A3

ITEM NO.	PART NUMBER	DESCRIPTION	
1	9305140	Hex Thin Nut M20x1.5	1
2	9104010	Deadman Swing Handle	1
3	9105040	Deadman Trigger w Switch	1
4	9301030	Cable White	1
5	9615490	3 PIN XLR Line Plugs AC3MM PD5302	1

08/10/2024



A
DMT HANDLE &
SWITCH ASSEMBLY
9301040



TRIGGER SWITCH

FIELD KIT = A + B


9301800: SINGLE PHASE
9301810: 3 PHASE

PUMP UPGRADE KIT
9501660

PUMP UPGRADE KIT
EXC. PUMP
9501690


9505030 NYLON HOSE KIT

9911560
PLUG



GEARBOX SECTION VIEW

9701430 COUPLING DRIVE
SET L100.25 & L100.28 FOR
VARI SPEED MOTOR



9505023
VARI SPEED MOTOR 2.2Kw

CONTROL BOX ASSEMBLY
9301510: VARI SPEED

VARI SPEED GEARBOX & MOTOR

ITEM NO.	PART NUMBER	DESCRIPTION	
6	9324070	Pump Mounting Plate	1
7	9304017	Pin - Coolant Pump	1
8	9405450	Coolant Pump	1
9	8705060	Socket Head Cap Screw M6x16	4
10	8705560	Hex Head Screw M8x20	2

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 23.07.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:

GEARBOX G MODEL ASSEMBLY

DO NOT SCALE DRAWING SCALE:1:7
DWG NO. 002002
REVISION 0
SHEET 3 OF 3 A3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9713000	Gearbox 2020	1
2	8705060	Socket Head Cap Screw M6x16	8
3	9405010	Oil Sight Window with Flat Gasket	1
4	9302120	Front Cover Plate	1
5	9305350	Shim Kit	1
6	9305020	Taper Roller Bearing 30x62x17.25 30206	1
7	9314000	Worm Shaft	1
8	9304430	Key Wormshaft 7x8x31	1
9	9305030	Taper Roller Bearing 30x72x20.75 30306	1
10	9315040	Oil Seal 52x30x7 (TC12495)	1
11	9312100	Retainer Ring	1
12	8705070	M6x20	4
13	9302110	Side Cover Plate	1
14	8705420	Flat Socket Head Cap Screw M10x25	1
15	9304130	Retainer Washer 55x10	1
16	8705090	Socket Head Cap Screw M6x35	3
17	9315090	Sum Plug 1/2" NPT	1
18	8705480	Socket Set Screw M8x12	1
19	9405450	Coolant Pump	1
20	9324070	Pump Mounting Plate	1
21	9304017	Pin - Coolant Pump	1
22	8705560	Hex Head Screw M8x20	2
23	9505030	Nylon Hose Kit 8mm	1
24	9314050	WormWheel	1
25	9305010	Double Seal 90x70x10	1
26	9504080	Main Spindle S315.S350	1
27	9314420	Key - Main Spindle	1
28	9504090	Spindle Counter Plate (S315D, S350D)	1
29	8715080	Dowel Pin 8x25	2
30	8735090	Retaining Screw Left Hand	1
31	9911560	M20 Plug	1



19.01.2024

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 25.10.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:


STANDARD GEARBOX ASSEMBLY S350

DO NOT SCALE DRAWING SCALE:1:5
DWG NO. 9935260
REVISION 0
SHEET 1 OF 2 A3

WORM GEAR DRIVE RATIO 1:33



SECTION VIEW



SECTION A-A

19.01.2024

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 25.10.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:

STANDARD GEARBOX ASSEMBLY S350

DO NOT SCALE DRAWING SCALE:1:2
DWG NO. 9935260
REVISION 0
SHEET 2 OF 2 A3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9713000	Gearbox 2020	1
2	8705060	Socket Head Cap Screw M6x16	8
3	9405010	Oil Sight Window with Flat Gasket	1
4	9302120	Front Cover Plate	1
5	9305350	Shim Kit	1
6	9305020	Taper Roller Bearing 30x62x17.25 30206	1
7	9314000	Worm Shaft	1
8	9304430	Key Wormshaft 7x8x31	1
9	9305030	Taper Roller Bearing 30x72x20.75 30306	1
10	9315040	Oil Seal 52x30x7 (TC12495)	1
11	9312100	Retainer Ring	1
12	8705070	M6x20	4
13	9302110	Side Cover Plate	1
14	8705420	Flat Socket Head Cap Screw M10x25	1
15	9304130	Retainer Washer 55x10	1
16	8705090	Socket Head Cap Screw M6x35	3
17	9315090	Sum Plug 1/2" NPT	1
18	8705480	Socket Set Screw M8x12	1
19	9405450	Coolant Pump	1
20	9324070	Pump Mounting Plate	1
21	9304017	Pin - Coolant Pump	1
22	8705560	Hex Head Screw M8x20	2
23	9505030	Nylon Hose Kit 8mm	1
24	9314050	WormWheel	1
25	9305010	Double Seal 90x70x10	1
26	**9814010**	**Main Spindle S400**	**1**
27	9314420	Key - Main Spindle	1
28	**9824000**	**Spindle Counter Plate S400**	**1**
29	**8715140**	**Dowel Pin 12x30**	**2**
30	8735090	Retaining Screw M16x40 (LEFT HAND Threaded)	1
31	9911560	M20 Plug	1



19.01.2024

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 25.10.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:

STANDARD GEARBOX ASSEMBLY S400

DO NOT SCALE DRAWING SCALE:1:5
REVISION 0
DWG NO. 9935270
SHEET 1 OF 1 A3

ITEM NO	PART NO	DESCRIPTION	QTY
1	9705880	STANDARD ENCLOSURE WITH LIDS 6 FLAT HD PHILLIP M4 x 16 ZP	1
2	3835190	MAIN SWITCH 20A EATON	1
3	9315220	CONTACTOR 24 VAC EATON	1
4	3875475	STAND BY LED 8061.924	1
5	9315190	TRANSFORMER INPUT 440/240 VAC OUTPUT 24VAC ALTRO	1
6	PD5367	PANEL SOCKET AMPHENOL	1
7	1045750	CABLE GLAND 5mm-10mm ALCD M16x1.5	2
8	9501280	POWER SUPPLY PLUG/LEAD 240V/15A	1
9	8745130	MOTOR SUPPLY CALBE 3 CORE 1.5mm2	1





ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN any FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 21.07.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:

COLD SAW 1 PHASE ENCLOSURE COMPONENTS

DO NOT SCALE DRAWING SCALE:1:2
DWG NO. 9301490
REVISION 0
SHEET 1 OF 1 A3

6	PD5367	PANEL SOCKET AMPHENOL	1
7	9305600	CABLE GLAND M20 x 1.5	1
8	1045750	CABLE GLAND M16 x 1.5	1
9	8715820	FLAT HD PHILLIP M4 x 16 ZP	6
10	8745150	MOTOR SUPPLY CALBE 6 CORE + E 1.5mm2	1
11	8745140	LINE SUPPLY CABLE 4 CORE 1.5mm2	1
12	9505200	WARNING LABEL	1

ITEM NO	PART NO	DESCRIPTION	QTY
1	9705880	STANDARD ENCLOSURE WITH LID	1
2	9305180	MAIN SWITCH 20A EATON	1
3	9315220	CONTACTOR 24 VAC EATON	1
4	3875475	STAND BY LED 8061.924	1
5	9315190	TRANSFORMER INPUT 440/240 VAC OUTPUT 24VAC ALTRO	1



ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 01.07.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:


COLD SAW 3 PHASE ENCLOSURE COMPONENTS

DO NOT SCALE DRAWING SCALE:1:2

DWG NO. 9301500

REVISION 2

SHEET 1 OF 1 A3



ITEM NO	PART NO	DESCRIPTION	QTY
1	9704004	VARI SPEED ENCLOSURE WITH LIDS	1
2	PD5367	PANEL SOCKET	1
3	9505028 (1)	RESET PUSH BUTTON	1
4	9505028 (2)	RESET DISK R	1
5	M22-A	FIXING ADAPTER	1
6	M22-K10	NO (NORMALLY OPEN) CONTACT	1
7	9305600	M20 CABLE GLAND	2
8	1045750	M16 CABLE GLAND	1
9	9501280	15A/240V PLUG/LEAD	1
10	8745140	4 CORE 1.5mm2 MOTOR CABLE	2.2m
11	8745290	3 CORE 1.5mm2 INVERTER SUPPLY CABLE	2.2m
12	8745150	7 CORE 1.5mm2 CABLE	2.2m
13	3835190	ON-OFF ROTARY SWITCH	1
14	9911510	10 kΩ POTENTIOMETER	1
15	8725820	DOUBLE SCREW CONNECTOR	1
16	8745370	6 TERMINAL CONNECTOR STRIP	1
17	-	EARTHING SCREW ASSEMBLY	1
18	A01582	1.5mm2 BOOT LACE PINS	1
19	8725230	⌀4 NON-INSULATED EYELET	4
20	8725210	⌀5 NON-INSULATED EYELET	4
21	AR0552	0.5mm2 BOOT LACE PINS	9
22	8745000	0.5mm2 SINGLE CORE 200m LENGTH CONTROL CABLE	6
23	8715820	6 FLAT HD PHILLIP M4 x 16 ZP	6
24	8745180	144mm CABLE TIES	-
25	9505200	WARNING LABEL	1

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN any FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 01.07.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:


COLD SAW VARI SPEED ENCLOSURE COMPONENTS

DO NOT SCALE DRAWING SCALE:1:2
REVISION 0
DWG NO. 9301510
SHEET 1 OF 1 A3


OPTIONAL




ISOLATOR: ONE PHASE




ISOLATOR: FRONT





CAM SWITCH

3835190 : 1 SPEED SWITCH 1PH
9305180: 2 SPEED SWITCH 3PH



	2	4	6	8	10	12	14	16
1		X			X			X
0								
2	X		X	X		X	X	

2 SPEED SWITCH DIAGRAM
1-0-2

COMPONENT / SCHEMATIC / WIRING DIAGRAMS FOR CONNECTION FOR 1 PHASE OR 3 PHASE CIRCUIT ISOLATOR

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 08.07.2020
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:
ISOLATOR SCHEMATIC

DO NOT SCALE DRAWING SCALE:1:2
DWG NO.
E2017.0331

REVISION 0
SHEET 1 OF 1 A3

OPTIONAL

6mm TUBING - BLUE

4mm TUBING - WHITE



LOWER BRACKET




AIR VICE

AIR INTAKE

GAUGE 12 BAR

AIR FR UNIT



MOUNT TO LOWER BRACKET




ROLLER VALVE

CAM

REDUCER

DOUBLE BANJO



PILOT/SPRING VALVE

SILENCER

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT


DRAWN ANH
DATE 10.07.2019
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:

PNEUMATIC DIAGRAM SINGLE AIR VICE

DO NOT SCALE DRAWING SCALE:1:4
DWG NO. -
REVISION 0
SHEET 2 OF 2 A3



ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 12.09.2019
MATERIAL:
WEIGHT: 12.67


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:

PNEUMATIC DIAGRAM DOUBLE AIR VICE

DO NOT SCALE DRAWING SCALE:1:4
DWG NO. -
REVISION 0
SHEET 2 OF 2 A3

OPTIONAL



ITEM	PART NO	DESCRIPTION	QTY
1	-	Coolant Tank	1
2	9925130	Nylon Tubing 6mm	1
3	-	Special Elbow 4-4	2
4	5000140	DP2005 Spray Unit	1
5	9724270	Lower Bracket Spray Mist M12	1
6	9935240	Roller Valve VM430-01-01S	1
7	9315910	Silencer	1
8	9604510	Special Shoulder Screw	1
9	9604520	Cam	1
10	9915450	Air Service Unit	1
11	8125550	Elbow 1/8 6mm	6
12	8705690	M4 Hex Nut	6
13	8725390	Socket Head Cap Screw M4x35	6
14	8705710	M6 Hex Nut	2
15	8705060	Socket Head Cap Screw M6x16	2

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 14.06.2019
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:

SAW SPRAY MIST DIAGRAM


DO NOT SCALE DRAWING SCALE:1:4
DWG NO. 9554050
REVISION 0
SHEET 1 OF 1 A3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9505540	Coolant Tank (Plastic)	1
2	9523040	Chip Basket	1
3	9505030	Tube Kit	1
4	9523050	Suction Head - Filter Assembly	1

01.12.2023



COOLANT TANK LOCATION



A **COOLANT TANK ASSEMBLY**

TOLERANCES ON DIMENSIONS ARE METRIC	SIZE	TO	MATCH	CAST*	GRADE	RA (µm)	GRADE	RA (µm)
DIMENSIONS ARE IN MILLIMETERS	6 mm		±0.1	±0.5	N1	0.025	N7	1.6
ANGULARITY TOLERANCE < ±0°10'	30 mm		±0.2	±0.5	N2	0.05	N8	3.2
CONCENTRICITY 0.1 mm	100 mm		±0.3	±1.5	N3	0.1	N9	6.3
REMOVE ALL BURRS & SHARP EDGES	300 mm		±0.5	±2.0	N4	0.2	N10	12.5
BY 0.3 x 45°	1000 mm		±0.6	±3.0	N5	0.4	N11	25.0
UNLESS OTHERWISE STATED	2000 mm		±1.2	±5.0	N6	0.8	N12	50.0

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN BY ANH
DATE 05.06.2020

MATERIAL: -

WEIGHT:

TITLE:

COOLANT TANK ASSEMBLY


DO NOT SCALE DRAWING SCALE:1:5

DWG NO.


9311110

REVISION 0

SHEET 1 OF 1 A3




ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9503130	Sheetmetal Stand	1
2	9503150	Saw Stand Shelf	1
3	9503160	Stand Brace	1
4	9503130.C08	Cover	1
5	8705120	Socket Head Cap Screw M8x20	2
6	8705720	Hex Nut M8	2
7	8705060	Socket Head Cap Screw M6x16	6
8	8705750	Hex Nut M6	6
9	9505017	Hinge	2
10	9503140	Saw Stand Door	1
11	9505016	Saw Stand Swing Handle (Latch Included)	1
12	8115080	Brobo Logo 65	1
13	9505018	"BROBO" Large	1



9503130 SHEETMETAL STAND			
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
14	9503130.C01	Front	1
15	9503130.C02	Back	1
16	9503130.C03	Top	1
17	9503130.C04	Rod	4
18	9503130.C05	Bended Equal Angle 1.6x50x515	2
19	9503150	Saw Stand Shelf	1

STAND ANGLE IRON (OPTIONAL)



ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT


DRAWN ANH
DATE 15.05.2020
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE: BROBO STANDARD STAND ASSEMBLY

DO NOT SCALE DRAWING SCALE:1:10
DWG NO. 9501740
REVISION 0
SHEET 1 OF 1 A3

ITEM NO.	PART NUMBER	DESCRIPTION	
1	8705340	Flat Socket Head Cap Screw M6x16	8
2	9314100	Jaw Wear Plate	1
3	9312090	Vice Jaw	1
4	8705500	Socket Set Screw Half Dog Point M8x25	1
5	8715210	Hex Thin Lock Nut M8	1
6	9704080	Vice Rod Extended Version	2
7	9304160	Cover Plate	1
8	9304120	Vice Nut (Brass)	1
9	8705270	Socket Head Cap Screw M12x60	2
10	9312050	Vice Block	1
11	9304170	Quick Action Nut	1
12	9714020	Vice Screw For New Clamping Table	1
13	9301440	Handle Crank	1
14	8705940	Rollpin ⌀4x24	1
15	1045020	Knob 38mm	1
16	9314090	Quick Action Handle	1
17	8735380	Roll Pin ⌀8x40	1
18	9314280	Vice Block Clamp	2
19	8705980	Rollpin ⌀6x16	1
20	9405090	Compression Spring	2
21	8705460	Socket Set Screw M6x8	2





ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 06.09.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:


MANUAL VICE ASSEMBLY
G MODEL

DO NOT SCALE DRAWING SCALE:1:3
DWG NO.
9711060

REVISION 0

SHEET 1 OF 2 A3

BROBO COLD SAW G MODE



ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 06.09.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:

MANUAL VICE ASSEMBLY G MODEL

DO NOT SCALE DRAWING SCALE:1:3
DWG NO.
9711060

REVISION 0
SHEET 2 OF 2 A3

ITEM NO.	PART NUMBER	DESCRIPTION	
1	8705340	Flat Socket Head Cap Screw M6x16	8
2	9314100	Jaw Wear Plate	1
3	9312090	Vice Jaw	1
4	8705500	Socket Set Screw Half Dog Point M8x25	2
5	8715210	Hex Thin Lock Nut M8	2
6	9704160	Vice Guide Rod G	2
7	9304160	Cover Plate 3mm	1
8	9304120	Vice Nut (Brass)	1
9	8705270	Socket Head Cap Screw M12x60	2
10	9312050	Vice Block	1
11	9304170	Quick Action Nut	1
12	9714020	Vice Screw For New Clamping Table	1
13	9301440	Handle Crank	1
14	8705940	Rollpin ⌀4x24	2
15	1045020	Knob 38mm	1
16	9314090	Quick Action Handle	1
17	8735380	Roll Pin ⌀8x40	1
18	9314280	Vice Block Clamp	2
19	8705980	Rollpin ⌀6x16	1
20	9405090	Compression Spring	2
21	9304015	Leadscrew Extension	1
22	9302260	Vice Extension Arm Block	1
23	9702250	Extension Arm G	1
24	8725470	Flat Washer ⌀10	1
25	8725960	Socket Head Cap Screw M10x40	1
26	9702240	Plate 76 x 30 x 20	1
27	8735540	Flat Countersink M6x40	2
28	8705460	Socket Set Screw M6x8	3



ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT


DRAWN ANH
DATE 06.09.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:

DUAL ARM VICE ASSEMBLY G MODEL

DO NOT SCALE DRAWING SCALE:1:3
DWG NO. **9701950**
REVISION 0
SHEET 1 OF 2 A3





ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT


DRAWN ANH
DATE 02.08.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:

TITLE:
DUAL ARM VICE ASSEMBLY G MODEL

DO NOT SCALE DRAWING SCALE:1:5
DWG NO.
9701950

REVISION 0





ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9504007	Nylon Wear Strip L90x100x15	2
2	9504005	Carriage 8x90x100L	2
3	9504000	Shaf Support 16	2
4	8726100	Button Head Socket Screw M6x16	4
5	12131X	Adjustable Hand Levers M10x40	2
6	9504850	Nylon Flat Washer M16 (30x 17x 3)	4
7	8705750	Hex Nut M16 ZINC PLATED	2
8	9505920	Micro Stop (Thumb Nut)	1
9	8735370	Stud M16x250	1
10	9504008	Clamping Pad 50x50x10	2
11	8705100	Socket Head Cap Screw M6x40	8
12	9504010	Rotation Arm	1
13	9504860	Nylon Bushes M16 (19x 16.1x17 + 34.5x3)	2
14	9504020	Mounting Plate Shape L2	1
15	9505930	Stop Plate 99 x 85 x 6	1
16	8705340	Flat Socket Head Cap Screw M6x16	5
17	8705070	Socket Head Cap Screw M6x20	3
18	9504830	45 Offset Indicator	1
19	8705930	Slotted Spring Pin 4x16	2
20	9702100	Extension Arm Stop 430	1
21	8705130	Socket Head Cap Screw M8x25	2
22	8705720	Hex Nut M8	2
23	9704840	Wear Plate 50x50x5	1
24	8705710	Hex Nut M6	2

TOLERANCES ON DIMENSIONS ARE METRIC	SIZE TO	MATCH	CAST*	GRADE	RA (µm)	GRADE	RA (µm)
DIMENSIONS ARE IN MILLIMETERS	6 mm	±0.1	±0.5	N1	0.025	N7	1.6
ANGULARITY TOLERANCE < ±0°10'	30 mm	±0.2	±0.5	N2	0.05	N8	3.2
CONCENTRICITY 0.1 mm	100 mm	±0.3	±1.5	N3	0.1	N9	6.3
REMOVE ALL BURRS & SHARP EDGES	300 mm	±0.5	±2.0	N4	0.2	N10	12.5
BY 0.3 x 45°	1000 mm	±0.6	±3.0	N5	0.4	N11	25.0
UNLESS OTHERWISE STATED	2000 mm	±1.2	±5.0	N6	0.8	N12	50.0

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN BY ANH
DATE 23.03.2023

MATERIAL: -

WEIGHT:

TITLE:

MICRO FLIP 430


DO NOT SCALE DRAWING SCALE:1:3


DWG NO. **9701560**

REVISION 0

SHEET 1 OF 5 A3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9701220	BROBO CONVEYOR C8030 3m WITH STAND	2
2	9701600	MANUAL LENGTH STOP 3M WITH BRACKETS	1
3	9701240	CONNECTING BRACKET RH C8030	1
4	9701250	CONNECTING BRACKET LH C8030	1





TOLERANCES ON DIMENSIONS ARE METRIC	SIZE TO	MATCH	CAST*	GRADE	RA (µm)	GRADE	RA (µm)
DIMENSIONS ARE IN MILLIMETERS	6 mm	±0.1	±0.5	N1	0.025	N7	1.6
ANGULARITY TOLERANCE < ±0°10'	30 mm	±0.2	±0.5	N2	0.05	N8	3.2
CONCENTRICITY 0.1 mm	100 mm	±0.3	±1.5	N3	0.1	N9	6.3
REMOVE ALL BURRS & SHARP EDGES	300 mm	±0.5	±2.0	N4	0.2	N10	12.5
BY 0.3 x 45°	1000 mm	±0.6	±3.0	N5	0.4	N11	25.0
UNLESS OTHERWISE STATED	2000 mm	±1.2	±5.0	N6	0.8	N12	50.0

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN BY ANH
DATE 23.03.2023

MATERIAL: -

WEIGHT:

TITLE:

BROBO LENGTH STOP KIT 3M

DO NOT SCALE DRAWING SCALE:1:20


DWG NO.


9701470

REVISION 0

SHEET 5 OF 8 A3

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	9701220	BROBO CONVEYOR C8030 3m WITH STAND	3
2	9701620	MANUAL LENGTH STOP 6M WITH BRACKETS	1
3	9701240	CONNECTING BRACKET RH C8030	1
4	9701250	CONNECTING BRACKET LH C8030	1
5	9702130	BROBO CONVEYOR LINK	2





TOLERANCES ON DIMENSIONS ARE METRIC	SIZE TO	MATCH	CAST*	GRADE	RA (µm)	GRADE	RA (µm)
DIMENSIONS ARE IN MILLIMETERS	6 mm	±0.1	±0.5	N1	0.025	N7	1.6
ANGULARITY TOLERANCE < ±0°10'	30 mm	±0.2	±0.5	N2	0.05	N8	3.2
CONCENTRICITY 0.1 mm	100 mm	±0.3	±1.5	N3	0.1	N9	6.3
REMOVE ALL BURRS & SHARP EDGES	300 mm	±0.5	±2.0	N4	0.2	N10	12.5
BY 0.3 x 45°	1000 mm	±0.6	±3.0	N5	0.4	N11	25.0
UNLESS OTHERWISE STATED	2000 mm	±1.2	±5.0	N6	0.8	N12	50.0

ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN BY ANH
DATE 23.03.2023

MATERIAL: -

WEIGHT:

TITLE:

BROBO LENGTH STOP KIT 6M


DO NOT SCALE DRAWING SCALE:1:25

DWG NO. **9701500**


REVISION 0


SHEET 8 OF 8 A3


AT REST
LOCATION




RHS 70x115










SHS105










RHS 150x85



ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 03.09.2021
MATERIAL:
WEIGHT:


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:


CUTTING CHART
S350 90 DEGREE


DO NOT SCALE DRAWING SCALE:1:6
REVISION 0
DWG NO.
S350G.00.CC
SHEET 1 OF 1 A3


AT REST LOCATION























ALL RIGHTS RESERVED. THIS DRAWING MAY NOT BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF BROBO GROUP PTY LT

DRAWN ANH
DATE 03.09.2021
MATERIAL:
WEIGHT:

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN MILLIMETERS
SURFACE FINISH:
TOLERANCES:
LINEAR:
ANGULAR:


TITLE:

CUTTING CHART S400 90 DEGREE

DO NOT SCALE DRAWING SCALE:1:6
DWG NO.
S400G.00.CC

REVISION 0

SHEET 1 OF 1 A3



DRAWN BY ANH 17/05/2023	STANDARD MANUAL COLD SAW DMT SCHEMATIC 1 PHASE 1 SPEED	

3 PIN PLUG

MAIN SUPPLY
1PH
15A
240 VAC
50Hz

E EARTH = GREEN/YELLOW

L1 ACTIVE = BROWN

L2 NEUTRAL = LIGHT BLUE

SW1

1 POLE ROTARY SWITCH

SW1: ON OFF SWITCH
Brand SCHRACK
Current Rating: 20A

INV: Inverter Delta
POT: Potentiometer 4.7kW
SB1: RESET PUSH BUTTON
DMT: DEAD MAN TRIGGER SWITCH

PARAMETER DELTA	CURRENT VALUE	DESCRIPTION
0.03	1	DISPLAY OPTION
1	95	MAX OUTPUT FREQUENCY %
1.02	220V	MAX OUTPUT 220V OR 460V 3PH
1.09	3	ACCEL TIME 1
1.1	3	DECEL TIME 1
2	1	0 TO +10V FROM AVI
2.01	1	EXTERNAL CONTROL
4.08	5	EXTERNAL RESET (NO CONTACT)
4.12	20	MIN AVI FREQUENCY
7	7.8 OR 3.9	MOTOR RATED CURRENT [WEG] CONNECTION (Δ) OR (Y)

R/L1 S/L2 E

DELTA VFD022EL21A

INV

VARIABLE FREQUENCY DRIVE

MAINS INPUT VOLTAGE
11:115V 1PH
21:230V 1PH
23:230V 3PH
43:460V 3PH

APPLICABLE MOTOR CAPACITY

002 : 0.25	HP (0.2kW)
004 : 0.5	HP (0.4KW)
007 : 1	HP (0.75KW)
015 : 2	HP (1.5KW)
022 : 3	HP (2.2KW)
037 : 5	HP (3.7KW)



ACM SIX/LIGHT BLUE — 0 Volts

AVI FIVE/GREEN — Wiper

10V FOUR/RED — +10 VDC

POT

DCM THREE/BLACK — Common + 24 V DC

MI3 TWO/BROWN — RESET

SB1

NO

DMT

MI1 ONE/WHITE — RUN FOWARD COMMAND

NO

W/T3


V/T2

U/T1

M1
3PH VARI SPEED
2.2 KW MOTOR
TERMINAL CONFIGURATION
DELTA

VARI SPEED MOTOR

M1



DRAWN BY ANH 18/05/2023	STANDARD MANUAL COLD SAW DMT SCHEMATIC SINGLE PHASE VARI SPEED 20-100 RPM	

3 PIN PLUG

MAIN SUPPLY
1PH
15A
240 VAC
50Hz


E EARTH = GREEN/YELLOW

L1 ACTIVE = BROWN

L2 NEUTRAL = LIGHT BLUE

SW1

1 POLE ROTARY SWITCH



AUSTRALIA 1PH 240V SUPPY
AUSTRALIA 3PH 415-440V
USA 3PH 220V
USA 3PH 460V

SW1: ON OFF SWITCH
Brand SCHRACK
Current Rating: 20A

INV: Inverter Nanjing AVF
POT: Potentiometer 4.7kW
SB1: RESET PUSH BUTTON
DMT: DEAD MAN TRIGGER SWITCH

INV

AVF5200A-S2-2R2G

VARIABLE FREQUENCY DRIVE

POWER RANGE
2R2-2.2kW
G—Constant torque load

INPUT CURRENT
24A
OUTPUT CURRENT
10A

Voltage degree

4T: 380(-15%)–440(+10%)
2T: 220(-15%)–240(+10%)
S2: 220(-15%)–240(+10%)

PARAMETERS	DEFAULT	BROBO SETTING	FUNCTION
P00.01	1	1	Choose Terminal Control Run or Stop
P00.03	50	95	Max Frequency
P00.04	50	95	Limit Max Frequency
P00.05	0	20	Min Frequency
P00.06	2	2	-
P00.07	2	1 or 0	Update to 1 or 0 to let P00.06 to be set
P00.11	10s	3s	Up Speed Time
P00.12	10s	3s	Down Speed Time
P05.01	1	1	FWD Terminal Control Run/Stop
P05.03	7	7	Fault Reset
P06.03	5	5	Fault Output Relay

R/L1 S/L2 E



GND SIX/LIGHT BLUE
0 Volts

AI1 FIVE/GREEN
Wiper

+10V FOUR/RED
+10 VDC

POT

GND THREE/BLACK
Commor + 24 V DC

S3 TWO/BROWN
RESET

S1 ONE/WHITE
RUN FOWARD COMMAND


SB1
NO
DMT
NO

W/T3
V/T2
U/T1


M1
3PH VARI SPEED
2.2 KW MOTOR
TERMINAL CONFIGURATION
DELTA

VARI SPEED MOTOR

M1



DRAWN BY ANH 22/05/2023	STANDARD MANUAL COLD SAW DMT SCHEMATIC SINGLE PHASE VARI SPEED 20-100 RPM	



	LEGEND
1	TRANSFORMER 415/24 VAC
2	TRIGGER SWITCH
3	STAND BY LED
4	CONTACTOR 24 VAC
5	2 SPEED ROTARY SWITCH
6	MOTOR TERMINAL
7	2 SPEED MOTOR WINDING 2.2 KW

ELECTRICAL SCHEMATIC 3 PHASE – 2 SPEED
STANDARD MANUAL COLD SAW

REV	DATE	DESCRIPTION	DRA.	SIGN
1	12/02/2025	ISSUED	ANH	
0	17/12/2018	ISSUED	ANH	

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the Internet or an intranet, without prior written permission from Brobo Group

DRAWN	
CHECK	
APPROVE	
ENGINEER	ANH

PROJECT: STANDARD COLD SAW 3 PHASE 2 SPEED

TITTLE: ELECTRICAL SCHEMATIC

SCALE NTS		REVISION 0
DWG NO.	E9301500	SHEET 1 OF 1

Brobo Group Warranty

1.1 The supplier warrants that all goods supplied by it, shall be free from defects in materials and workmanship for a period of twelve(12) months from the date of delivery to the Customer. ("The Warranty Period"), on the following terms and conditions.

1.2 The Customer shall promptly provide written particulars to the supplier on becoming aware of any defect in the goods during the Warranty Period, and shall provide the Supplier with all necessary access, facilities and information to enable the Supplier to ascertain or verify the nature and the cause of the defect and to carry out its obligations under this warranty.

1.3 The Supplier's obligation under this warranty is limited to repairs of the defect goods and the Supplier is under no obligation to replace the goods or refund the value of the goods to the Customer.

1.4 If the goods are, in the opinion of the Supplier, not defective or if any defect is attributable to any one or more of the following circumstances then the Supplier is under no obligation whatsoever to the Customer:

1.4.1 The use of the goods for a purpose other than that for which they were intended to be used;

1.4.2 The repair, modification or alteration of the goods by any person other than the Supplier;

1.4.3 Where the defect has arisen due to misuse, neglect or accident, howsoever arising;

1.4.4 Where the defect has arisen due to installation of the goods which were, in the reasonable opinion of the Supplier, incorrectly carried out

1.4.5 Where the goods have not been correctly stored or maintained

1.4.6 Where the defect has arisen due to normal wear and tear on the goods

1.5 The Supplier is under no obligation under this warranty where the Customer has failed to observe the terms of payment for the goods or any other obligation imposed by the terms and conditions of this warranty.

1.6 In the event that the Supplier is supplying goods, which have been manufactured by third parties, the Customer shall be entitled to the benefit of any Manufacturer's Warranty in respect of such goods. The Customer acknowledges that the Supplier accepts no responsibility whatsoever for any Manufacturer's Warranty or any claim howsoever arising from the use of the goods, whether singularly or in combination with other products.

1.7 The Supplier shall not be liable for any indirect or consequential losses or expenses suffered by the Customer, howsoever caused.

1.8 Except as specifically set out herein, or in writing by way of catalogue or pamphlet or otherwise provided by the Supplier to the Customer any term, representation, condition or warranty in respect of the quality, condition or description of the goods, whether implied by statute, common law, trade usage, custom or otherwise, is hereby expressly excluded.

This warranty is provided in addition to other rights and remedies you have under law: Our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.